

The DS3408 digital scanner defaults to Auto Aim trigger mode. In this mode, the digital scanner's red laser aiming pattern is automatically turned on when the digital scanner senses motion. After 2 seconds of inactivity, the red laser aiming pattern automatically shuts off.

To turn off the default Auto Aim trigger mode, scan the **Level** bar code below. In the Level trigger mode, a trigger pull activates the red laser aiming pattern and decode processing. Decode processing continues until the bar code is decoded, the trigger is released, or the Decode Session Timeout is reached.



Level
(00h)

Note: The default Auto Aim and Level trigger modes apply to the DS3408 digital scanner only. These modes do not apply to the LS3408 scanner.

For more information about trigger modes and all parameters for the DS3408 digital scanner, refer to the *DS3408 Product Reference Guide* (p/n 72E-68456-xx).



72-78772-01

Revision A - December 2005

Symbol Technologies, Inc. One Symbol Plaza Holtville, NY 11742-1300